

Manual, Assembly instruction: Brodit 856141

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount over the frame surrounding the right center air vent.
2. Pull the lower part of the mount downward and press forward so the lower edge hooks under the dashboard panel.
3. The ProClip mount is in place.
4. The ProClip mount is in place.