

Manual, Assembly instruction: Brodit 856145

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hold the mount so the faceplate angles toward the driver. Place the upper edge of the mount into the gap at the top of the center air vent divider.
2. Press upward and forward on the bottom of the mount, until the lower edge hooks + clips into the gap between the air vent housing and the trim.
3. Press on the mount so it is properly in place.
4. The ProClip mount is in place.