

Manual, Assembly instruction: Brodit 856146

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the included Gap Opener (Spaltöffner) into the gap between the hard and padded dashboard panels, to widen the gap.
2. Insert the lower edge of the mount, with a block, into the gap next to the Gap Opener (Spaltöffner).
3. Rotate the mount upwards so the lower edge hooks behind the hard dashboard panel. Press downward and forward on the top of the mount, until the upper edge hooks + clips into the gap under the dashboard overhang. Pull out the Gap Opener (Spaltöffner).
4. The ProClip mount is in place.