

Manual, Assembly instruction: Brodit 856152

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the curved edge on the upper part of the mount under the frame surrounding the air vent.
2. Press forward on the bottom of the mount so the lower edge hooks over the frame surrounding the air vent.
3. The mount may be installed on any air vent.
4. The ProClip mount is in place.