

Manual, Assembly instruction: Brodit 856154

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Position the mount just to the left side of the screen. Hook the lower edge of the mount into the gap in front of the screen panel.
2. Rotate the mount upwards. Place the top stem of the mount on top of the screen panel. Align the screw holes on each part of the mount. Ensure the top edge conforms to the profile of the screen panel.
3. Use the included screws to secure the mount together, so the mount sits firmly in place.
4. The ProClip mount is in place.