

Manual, Assembly instruction: Brodit 856155

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Observe the mount from the side. The stems slightly angle upward. Hook the edge of the upper stem onto the top air vent housing.

2. Press upward and forward on the bottom of the mount, until the lower edge hooks + clips onto the lower air vent housing.

3. The mount may be installed on either center vent.

4. The ProClip mount is in place.