

Manual, Assembly instruction: Brodit 856157

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount under the top frame surrounding the air vent.
2. Press forward on the bottom of the mount so the lower edge clips + hooks onto the bottom frame surrounding the air vent.
3. The mount may be installed on either center air vent.
4. The ProClip mount is in place.