

Manual, Assembly instruction: Brodit 856162

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount at the bottom right corner of the screen. Hook the left edge under the frame surrounding the screen.

2. Flex + Pull the mount to the right. Press the right edge into the gap between the center panel and the center console sidewall. The lip on the stem will click onto the dashboard face

3. The ProClip mount is in place.

4. The ProClip mount is in place.