

Manual, Assembly instruction: Brodit 856163

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Set the screen in its highest position. Hold the mount over the screen so the mounting plate is on the drivers side.

2. Slowly and firmly, press down on both sides of the mount to slide/hook it onto the screen. Gently flex the sides out to ease the installation. Press downward until the mount is securely in place.

3. The ProClip mount is in place, the screen is in its lowest position. The mount will not interfere with the adjustment of the screen height.

4. The ProClip mount is in place, the screen is in its highest position.