

Manual, Assembly instruction: Brodit 856167

Center mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper part of the mount into the gap between the frame surrounding the screen and the padded trim.

2. Press downward on top of the mount so the angled edge goes all the way into the gap.

3. Press the thin end of the included Gap Opener (Spaltöffner) into the gap between the trim and the center console, to widen the gap. Press forward on the lower part of the mount so the angled edge hooks behind the trim. Pull out the Gap Opener (Spaltöffner).

4. The ProClip is in place.