

Manual, Assembly instruction: Brodit 856168

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the thin end of the included Gap Opener (Spaltöffner)s into the gap between the control panel and the air vent housing, to widen the gap. Place them so the mount will fit between them. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the lower edge of the mount into the gap between the Gap Opener (Spaltöffner)s.

2. Firmly press downwards and forwards on top of the mount so the upper edge hooks + clips into the gap between the top dashboard panel and the air vent housing. Pull out the Gap Opener (Spaltöffner)s. Press on each part of the mount so the edges are fully in place in the gaps.

3. This mount can be placed anywhere within the width of the control panel.

4. The ProClip mount is in place.