

Manual, Assembly instruction: Brodit 856169

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hold the mount over the screen so the faceplate is on the drivers side of the screen. Flex the sides of the mount outward and slide downward over the screen.

2. Slide the mount downward until the top of the mount is flush with the top of the screen. The mount can be worked down one side at a time if needed.

3. The ProClip mount is in place.

4. The ProClip mount is in place.