

Manual, Assembly instruction: Brodit 856176

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the upper edge of the mount upwards into the gap between the air vent housing and the dashboard panel.
2. Press upward and forward on the lower part of the mount. Hook the lower edge onto the frame surrounding the air vent.
3. The mount may be installed in any position along the center air vents.
4. The ProClip mount is in place.