

Manual, Assembly instruction: Brodit 856183

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Rest the groove of longer lower edge of the mount on the air vent frame.
2. Rotate the mount upward. Press forward on the top of the mount until the upper edge hooks + clips under the air vent frame. Ensure the lower edge now hooks onto the back edge of the bottom air vent frame.
3. The mount can be placed on either center air vent.
4. The ProClip mount is in place.