

Manual, Assembly instruction: Brodit 856185

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the flat lower edge of the mount onto the air vent frame.
2. Press forward on the top of the mount until the upper edge snaps + clips onto the air vent frame. Make sure the lower edge is properly hooked behind the lower air vent frame.
3. The mount can be installed on either center vent.
4. The ProClip mount is in place.