

Manual, Assembly instruction: Brodit 856192

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled edge on the upper part of the mount under the frame surrounding the air vent.
2. Press the lower part of the mount upward and forward. Hook the angled edge over the frame surrounding the air vent. Press on the mount so the adhesive tape attaches properly.
3. This mount can be placed anywhere within the width of the air vent.
4. The ProClip mount is in place.