

Manual, Assembly instruction: Brodit 856199

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount over the inside edge of the frame surrounding the air vent.
2. Press forward on the top of the mount until the upper edge hooks + clips onto the edge of the frame surrounding the air vent. Press on the inside of each lip and ensure they are each fully secured to the vent.
3. The mount may be installed as desired along the center vents.
4. The ProClip mount is in place.