

Manual, Assembly instruction: Brodit 856201

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the edge of the shorter stem on the mount onto the left frame surrounding the air vent. Adjust upward + downward into desired position.
2. Press on the right side of the mount until the right stem clips onto the right air vent frame
3. The mount may be installed upside down on the right vent for use by the passenger.
4. The ProClip mount is in place.