

Manual, Assembly instruction: Brodit 856202

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin end of the included Gap Opener (Spaltöffner) into the seam at the top corner of the panel around the air vent.

2. Gently press the double-bent lower edge of the mount into the seam next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

3. Rotate the mount back against the dashboard. The lower edge will draw fully into the seam and hook into place. Clip the upper lip into the seam at the back of the dashboard trim. Press on the mount to ensure it is fully seated.

4. The ProClip mount is in place.