

Manual, Assembly instruction: Brodit 856209

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled upper edge of the mount over + behind the frame surrounding the screen.
2. Keep the upper edge of the mount in position. Pull the lower part of the mount downward and angle the lower edge outward a bit. Press forward on the lower part and hook the angled edge under + behind the frame surrounding the screen.
3. The ProClip mount is in place.
4. The ProClip mount is in place.