

Manual, Assembly instruction: Brodit 856214

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower lip of the mount on the back left part of the dash panel behind the screen.
2. Pull on the front of the mount and hook the upper lip on the front edge of the dashboard panel.
3. Shift the mount to the right to increase tension. Position the mount as desired.
4. The ProClip mount is in place.