


Manual, Assembly instruction: Brodit 856215

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Position the faceplate behind the mount so it faces toward you. Attach the faceplate to the mount using the included screws.
2. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount behind the infotainment screen so the face plate is on the right side. Hook the right lip on the screen frame.
3. Flex the left lip out and hook it over the left side of the screen.
4. The ProClip mount is in place.