

Manual, Assembly instruction: Brodit 856217

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the left side of the mount on the left of the screen. Slide the side down until it stops
2. Flex the right side of the mount out and over the right side of the screen. Ensure the mount is fully seated down over the screen
3. The ProClip mount is in place.
4. The ProClip mount is in place.