

Manual, Assembly instruction: Brodit 856221

Center mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the thin end of the included Gap Opener (Spaltöffner) into the gap between the center console panel and the compartment, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled edge on the upper part of the mount into the gap next to the Gap Opener (Spaltöffner).

2. Press the lower part of the mount upward and forward.

3. Press forward on the lower part of the mount and hook the angled edge into the gap between the console frame and the compartment. Pull out the Gap Opener (Spaltöffner).

4. The ProClip mount is in place.