

Manual, Assembly instruction: Brodit 856230

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Position the mount as preferred along the center air vents. Gently press the mount into the air vent until the top and bottom lips clip onto the air vent trim
2. Check to ensure the lips are seated squarely on the trim panels.
3. The mount may be installed anywhere within the width of the center air vents.
4. The ProClip mount is in place.