

Manual, Assembly instruction: Brodit 856235

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount under the frame surrounding the air vent.
2. Press the upper edge of the mount downward and forward. Hook the upper edge of the mount under the frame surrounding the air vent.
3. The ProClip mount is in place. The mount may be installed anywhere within the width of the air vents.
4. The ProClip mount is in place.