


Manual, Assembly instruction: Brodit 856236

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount round onto the panel surrounding the compartment.

2. Press the upper part of the mount downward and forward.

3. Press forward on the upper part of the mount so the upper edge hooks under the panel surrounding the compartment.

4. The ProClip mount is in place.