

Manual, Assembly instruction: Brodit 856238

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount over the frame surrounding the air vent.
2. Press the mount upward and forward. Press forward on the upper part of the mount so the edge hooks under the frame surrounding the air vent.
3. The mount may be placed anywhere within the width of the air vents.
4. The ProClip mount is in place.