

Manual, Assembly instruction: Brodit 856252

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Ensure the t-slot nuts are flush with the end of the screws and aligned with the width of the mount.
2. Choose a position as desired along the accessory rail. Place the nuts inside the rail.
3. Tighten the screws to secure the mount in place. Maintain slight back tension after the T-nuts are perpendicular to the slot to keep them engaged, while tightening the screws.
4. The ProClip mount is in place. You can attach multiple mounts to the rail at the same time.