

Manual, Assembly instruction: Brodit 856253

Center mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount into the gap between the air vent housing and the surrounding frame.
2. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press downward and forward on top of the mount so the upper edge goes into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
3. The mount may be placed anywhere within the width of the air vents.
4. The ProClip mount is in place.