

Manual, Assembly instruction: Brodit 856260

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the grooved upper edge of the mount under the frame surrounding the air vent.
2. Press the lower part of the mount upward and forward. Hook the grooved lower edge over the frame surrounding the air vent.
3. The mount may be placed as desired within the width of the air vent.
4. The ProClip mount is in place.