

Manual, Assembly instruction: Brodit 856282

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the notched upper edge of the mount into the gap between the air vent housing and surrounding frame. There is a tab in the seam near the center of the air vent. If encountered, adjust the mount position off to the side so the mount notch goes around the tab.
2. Press forward on the bottom of the mount until the lower edge hooks + clips onto the air vent frame.
3. The mount may be placed as desired along either center vent.
4. The ProClip mount is in place.