

Manual, Assembly instruction: Brodit 856286

Angled mount

1.)



2.)



3.)



4.)



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Gently press the included Gap Opener (Spaltöffner) into the gap between the accessory tray and the dashboard trim.

2. Position the mount at the far left end of the accessory tray. Press the upper edge of the mount into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

3. Lift the bottom of the mount upward and over the accessory tray raised edge. Hook the lower edge of the mount onto the inside of the accessory tray raised edge.

4. The ProClip mount is in place.