

Manual, Assembly instruction: Brodit 856287

Center mount

1.)



2.)



3.)



4.)



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the lower edge of the mount onto the frame surrounding the air vent.
2. Press the top of the mount forward until the upper edge clips under the frame.
3. Position the mount as desired along the center air vents..
4. The ProClip mount is in place.