

## Manual, Assembly instruction: Brodit 856295

Center mount

1.)

2.)



3.)

4.)



**Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.**

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Press the edge of the mount into the gap between the air vent housing and the surrounding panel.
2. Press the included Gap Opener (Spaltöffner) into the gap on the accessory tray + infotainment screen side of the dashboard panel.
3. Flex + Pull the mount over the side of the dashboard panel and insert the edge into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
4. The mount may be installed on either side of the center accessory tray + infotainment screen.