



Product 215547



215547 Mount Tilt swivel mount.

Keep your PNA GPS device in a holder attached to the dashboard, and you will always have it within easy reach! You can easily take the device with you when leaving the vehicle. The holder can be adjusted in order to avoid light reflection on the screen.

With this tilt swivel mount you can have your PNA installed on the dashboard. You use the original mount that comes with the PNA and press it onto the tilt swivel mount, which you can attach onto the ProClip Mounting Platform. This will give you a firm, neat installation.

EAN: 7320282155476

Item no 215547 fits:

- Garmin 3597LMT (For all countries)
- Garmin Aera 500 (For all countries)
- Garmin Aera 510 (For all countries)
- Garmin Aera 550 (For all countries)
- Garmin Aera 560 (For all countries)
- Garmin Asus A10 (For all countries)
- Garmin Camper 780 (For all countries)
- Garmin Garmin Drive 40LM (For all countries)
- Garmin Garmin Drive 50LM (For all countries)
- Garmin Garmin Drive 60LMT (For all countries)
- Garmin Garmin DriveAssist 50LMT (For all countries)
- Garmin Garmin DriveAssist 50LMT-D (For all countries)
- Garmin Garmin DriveLuxe 50LMT (For all countries)
- Garmin Garmin DriveLuxe 50LMT-D (For all countries)
- Garmin Garmin DriveSmart 50LM (For all countries)
- Garmin Garmin DriveSmart 50LMT (For all countries)
- Garmin Garmin DriveSmart 50LMT-D (For all countries)
- Garmin Garmin DriveSmart 60LM (For all countries)
- Garmin Garmin DriveSmart 60LMT (For all countries)
- Garmin Garmin DriveSmart 60LMT-D (For all countries)
- Garmin Garmin DriveSmart 61LMT (For all countries)
- Garmin Garmin DriveSmart 61LMT-D (For all countries)
- Garmin Garmin DriveSmart 70LM (For all countries)
- Garmin Garmin DriveSmart 70LMT (For all countries)
- Garmin Garmin DriveSmart 70LMT-D (For all countries)
- Garmin Garmin DriveTrack 70LM (For all countries)
- Garmin Garmin fleet 590 (For all countries)
- Garmin Nüvi 1100 (For all countries)
- Garmin Nüvi 1100LM (For all countries)
- Garmin Nüvi 1200 (For all countries)
- Garmin Nüvi 1260T (For all countries)

Garmin Nüvi 1300 (For all countries)
Garmin Nüvi 1300LM (For all countries)
Garmin Nüvi 1300T (For all countries)
Garmin Nüvi 1310T (For all countries)
Garmin Nüvi 1340T (For all countries)
Garmin Nüvi 1350 (For all countries)
Garmin Nüvi 1350LMT (For all countries)
Garmin Nüvi 1350T (For all countries)
Garmin Nüvi 1370T (For all countries)
Garmin Nüvi 1390LMT (For all countries)
Garmin Nüvi 1390T (For all countries)
Garmin Nüvi 1440 (For all countries)
Garmin Nüvi 1450 (For all countries)
Garmin Nüvi 1450LM (For all countries)
Garmin Nüvi 1450LMT (For all countries)
Garmin Nüvi 1450T (For all countries)
Garmin Nüvi 1490LMT (For all countries)
Garmin Nüvi 1490T (For all countries)
Garmin Nüvi 1490TV (For all countries)
Garmin Nüvi 1690 (For all countries)
Garmin Nüvi 1695 (For all countries)
Garmin Nüvi 200 (For all countries)
Garmin Nüvi 200W (For all countries)
Garmin Nüvi 205 (For all countries)
Garmin Nüvi 205W (For all countries)
Garmin Nüvi 2200 (For all countries)
Garmin Nüvi 2240 (For all countries)
Garmin Nüvi 2250 (For all countries)
Garmin Nüvi 2250LT (For all countries)
Garmin Nüvi 2300 (For all countries)
Garmin Nüvi 2300LM (For all countries)
Garmin Nüvi 2350 (For all countries)
Garmin Nüvi 2350LMT (For all countries)
Garmin Nüvi 2350LT (For all countries)
Garmin Nüvi 2360LMT (For all countries)
Garmin Nüvi 2360LT (For all countries)
Garmin Nüvi 2370LT (For all countries)
Garmin Nüvi 2440 (For all countries)
Garmin Nüvi 2445 (For all countries)
Garmin Nüvi 2445LM (For all countries)
Garmin Nüvi 2445LMT (For all countries)
Garmin Nüvi 2447LM (For all countries)
Garmin Nüvi 2447LMT (For all countries)
Garmin Nüvi 2450 (For all countries)
Garmin Nüvi 2450LM (For all countries)
Garmin Nüvi 2455 (For all countries)
Garmin Nüvi 2455LM (For all countries)
Garmin Nüvi 2455LMT (For all countries)
Garmin Nüvi 2455LT (For all countries)
Garmin Nüvi 2457LMT (For all countries)
Garmin Nüvi 2460 (For all countries)
Garmin Nüvi 2460LMT (For all countries)
Garmin Nüvi 2460LT (For all countries)
Garmin Nüvi 2467LM (For all countries)
Garmin Nüvi 2475LT (For all countries)
Garmin Nüvi 2495LMT (For all countries)
Garmin Nüvi 2497LM (For all countries)
Garmin Nüvi 2497LMT (For all countries)
Garmin Nüvi 250 (For all countries)
Garmin Nüvi 250W (For all countries)
Garmin Nüvi 2539LMT (For all countries)
Garmin Nüvi 2545 (For all countries)

Garmin Nüvi 2545LM (For all countries)
Garmin Nüvi 2545LMT (For all countries)
Garmin Nüvi 2547LM (For all countries)
Garmin Nüvi 2547LMT (For all countries)
Garmin Nüvi 255 (For all countries)
Garmin Nüvi 2555LM (For all countries)
Garmin Nüvi 2555LMT (For all countries)
Garmin Nüvi 2555LT (For all countries)
Garmin Nüvi 2557LMT (For all countries)
Garmin Nüvi 2558LMTHD (For all countries)
Garmin Nüvi 2559LM (For all countries)
Garmin Nüvi 2559LMT (For all countries)
Garmin Nüvi 255W (For all countries)
Garmin Nüvi 2567LM (For all countries)
Garmin Nüvi 2569LMT-D (For all countries)
Garmin Nüvi 2577LT (For all countries)
Garmin Nüvi 2585TV (For all countries)
Garmin Nüvi 2589LM (For all countries)
Garmin Nüvi 2589LMT (For all countries)
Garmin Nüvi 2595LMT (For all countries)
Garmin Nüvi 2597LM (For all countries)
Garmin Nüvi 2597LMT (For all countries)
Garmin Nüvi 2598LMTHD (For all countries)
Garmin Nüvi 2599LMT-D (For all countries)
Garmin Nüvi 2599LMTHD (For all countries)
Garmin Nüvi 260 (For all countries)
Garmin Nüvi 260W (For all countries)
Garmin Nüvi 265 (For all countries)
Garmin Nüvi 2659LM (For all countries)
Garmin Nüvi 265T (For all countries)
Garmin Nüvi 265W (For all countries)
Garmin Nüvi 265WT (For all countries)
Garmin Nüvi 2689LMT (For all countries)
Garmin Nüvi 2699LMT-D (For all countries)
Garmin Nüvi 2699LMTHD (For all countries)
Garmin Nüvi 270 (For all countries)
Garmin Nüvi 275T (For all countries)
Garmin Nüvi 2797LMT (For all countries)
Garmin Nüvi 285W (For all countries)
Garmin Nüvi 295W (For all countries)
Garmin Nüvi 30 (For all countries)
Garmin Nüvi 300 (For all countries)
Garmin Nüvi 310 (For all countries)
Garmin Nüvi 3450 (For all countries)
Garmin Nüvi 3450LM (For all countries)
Garmin Nüvi 3490LMT (For all countries)
Garmin Nüvi 350 (For all countries)
Garmin Nüvi 350LM (For all countries)
Garmin Nüvi 3540LT (For all countries)
Garmin Nüvi 3550LM (For all countries)
Garmin Nüvi 3590LMT (For all countries)
Garmin Nüvi 3597LMT (For all countries)
Garmin Nüvi 3597LMTHD (For all countries)
Garmin Nüvi 3598LMTD (For all countries)
Garmin Nüvi 360 (For all countries)
Garmin Nüvi 370 (For all countries)
Garmin Nüvi 3750 (For all countries)
Garmin Nüvi 3760LMT (For all countries)
Garmin Nüvi 3760T (For all countries)
Garmin Nüvi 3790LMT (For all countries)
Garmin Nüvi 3790T (For all countries)
Garmin Nüvi 390LM, Europe (For all countries)

Garmin Nüvi 40 (For all countries)
Garmin Nüvi 40LM (For all countries)
Garmin Nüvi 42 (For all countries)
Garmin Nüvi 42LM (For all countries)
Garmin Nüvi 44 (For all countries)
Garmin Nüvi 44LM (For all countries)
Garmin Nüvi 465LMT (For all countries)
Garmin Nüvi 465T (For all countries)
Garmin Nüvi 50 (For all countries)
Garmin Nüvi 500 (For all countries)
Garmin Nüvi 5000 (For all countries)
Garmin Nüvi 50LM (For all countries)
Garmin Nüvi 52 (For all countries)
Garmin Nüvi 52LM (For all countries)
Garmin Nüvi 54 (For all countries)
Garmin Nüvi 54LM (For all countries)
Garmin Nüvi 55 (For all countries)
Garmin Nüvi 550 (For all countries)
Garmin Nüvi 55LM (For all countries)
Garmin Nüvi 55LMT (For all countries)
Garmin Nüvi 56 (For all countries)
Garmin Nüvi 56LM (For all countries)
Garmin Nüvi 600 (For all countries)
Garmin Nüvi 610 (For all countries)
Garmin Nüvi 650 (For all countries)
Garmin Nüvi 660 (For all countries)
Garmin Nüvi 670 (For all countries)
Garmin Nüvi 680 (For all countries)
Garmin Nüvi 710 (For all countries)
Garmin Nüvi 750 (For all countries)
Garmin Nüvi 755T (For all countries)
Garmin Nüvi 760 (For all countries)
Garmin Nüvi 765T (For all countries)
Garmin Nüvi 770 (For all countries)
Garmin Nüvi 775T (For all countries)
Garmin Nüvi 780 (For all countries)
Garmin Nüvi 785T (For all countries)
Garmin Nüvi 850 (For all countries)
Garmin Nüvi 855 (For all countries)
Garmin Nüvi 860 (For all countries)
Garmin Nüvi 880 (For all countries)
Garmin Nüvi 885T (For all countries)
Garmin SafeNav Powered by Garmin (For all countries)
Garmin Street Pilot c510 (For all countries)
Garmin Street Pilot c530 (For all countries)
Garmin Street Pilot c550 (For all countries)
Garmin Street Pilot c580 (For all countries)
Garmin Street Pilot i2/i3/i5/2720 (For all countries)
Garmin Zumo 340LM (For all countries)
Garmin Zumo 350LM (For all countries)
Garmin Zumo 390LM (For all countries)
Garmin Zumo 590LM (For all countries)
Garmin Zumo 660 (For all countries)
Garmin Zumo 660LM (For all countries)
Garmin dezl 560LMT (For all countries)
Garmin dezl 560LT (For all countries)
Garmin dezl 56LT (For all countries)
Garmin dezl 570LMT (For all countries)
Garmin dezl 570LMT-D (For all countries)
Garmin dezl 760LMT (For all countries)
Garmin nüLink! 1695 LIVE (For all countries)
Garmin nüLink! 2340 LIVE (For all countries)

Garmin nüLink! 2390 LIVE (For all countries)

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the mount.

1. Place the tilt swivel mount in the desired position. Screw the mount into place with the enclosed screws.

2. The tilt swivel mount is in place. This mount fits a number a devices, the installation procedure may vary but the principal is similar for all devices.

3. Installation of Nüvi etc: For the installation, you will use the original mount that comes with the PNA and press it onto the tilt swivel mount. Place the original mount by the tilt swivel mount so the tilt swivel fits. Press the original mount onto the tilt swivel mount, press until you feel it is properly in place.

4. Installation of Street Pilot etc: Place the device by the tilt swivel mount so the tilt swivel fits. Press the device onto the tilt swivel mount, press until you feel it is properly in place.
