

Product 216001



216001 Accessories Locking block with 2 keys. To be used with Item no: 216000.

Locking block for use with item no 216000. Transforms a passive holder into a holder with a locking feature, enables you to lock your Garmin in place in the holder. Two keys included. Made of high grade Acetal plastic. Color: Black. Made in Sweden.

EAN: 7320282160012

Item no 216001 fits:

- Garmin Fleet 770 (For all countries)
- Garmin Fleet 780 (For all countries)
- Garmin Fleet 790 (For all countries)
- Garmin dezl 780 LMT-D (For all countries)
- Garmin dezlCam 785 LMT-D (For all countries)

INSTALLATION INSTRUCTIONS



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Screw the holder onto the attaching plate. Tighten the screw so the holder is firmly in place, but still can be adjusted.

2. To place the device in the holder: Place the lower part of the device in the dock, then flip/press the upper part forwards so it snaps into place in the holder. Push the lock downwards and press the button on its side to lock the unit into the holder.

3. To remove the device from the holder: Use the enclosed key to open the lock. Slide the lock upwards. Release the device from the dock by pressing the button on the top side of the dock, in the same time pull the upper part of the device out from the dock and then lift the device up and out from the holder.

4. The holder is in place.
