

Manual, Assembly instruction: Brodit 216126

Extra strength holder. For device with rugged frame. Battery swap slot. With lock, 2 keys included. With AMPS, Vesa 75 holes.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Place the holder onto the desired position and screw into place with the enclosed screws. To place the device in the holder: Place the lower part of the device in the holder. Flip/press the upper part of the device forward so it snaps into place in the holder. Press the locking block downward. Press the button to lock.

2. To remove the device from the holder: Open the lock with the key. Pull the locking block upward. Press upwards on the upper part of the holder, at the same time pull the upper part of the device out from the holder. Lift the device up and out from the holder.

3. Battery swap slot: it is easy to swap battery.

4. The holder is in place.