



Manual, Assembly instruction: Brodit 216175

For use with Apple MagSafe Charger (Apple article no. MHXH3ZM/A, MX6X3ZM/A, MGD74ZM/A, MGDM4ZM/A) (Not included). ONLY compatible with Apple MagSafe devices or Apple MagSafe accessories.
Cig-plug adapter with 2 USB ports: Type-C + Type-A.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the mount so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the mount over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw so the mount is firmly in place, but still can be adjusted.

2. Carefully press the MagSafe Charger downward and forward so it goes into the mount, tighten the fixing screw.

3. Remove the MagSafe charger from the mount: First loosen the fixing screw then push the MagSafe charger out of the mount.

4. The mount is in place. The mount to hold an Apple MagSafe Charger is designed for use in ordinary driving conditions. Please be aware that in certain situations, such as driving on bumpy roads or a sudden braking/maneuvering of a vehicle, it is possible that the Apple MagSafe Charger device may be dislodged from the mount holding it. Use of the mount holding an Apple MagSafe Charger is at the user's sole discretion and risk. Brodit AB is not responsible for any damage caused by a device being dislodged from the mount holding a MagSafe Charger.