

Product 216176



216176 Mount with tilt swivel For use with Apple MagSafe Charger (Apple article no. MHXH3ZM/A) (Not included). ONLY compatible with Apple MagSafe devices or Apple MagSafe accessories. With support under the device.

Keep your iPhone battery fully charged in a mount for MagSafe Charger, always within easy sight and reach! Neat, discreet and convenient. Custom made with a perfect, firm fit. The iPhone is held securely in place in an upright position for maximum cellular reception. The Mount is equipped with an support under the device.

The mount is equipped with a tilt swivel so you can easily adjust the angle for better viewing. Tilts 17° and swivels 360°. Mounting plate 42x50 mm with 4 mm AMPS-holes. Made of high grade black ABS/Acetal plastic. Made in Sweden. Attach onto a ProClip mounting platform.

This mount is to be used with Apple MagSafe Charger.
Note! MagSafe Charger not included, (Apple article. no. MHXH3ZM/A).

EAN: 7320282161767

Item no 216176 fits:

- Apple iPhone 12 (For all countries)
- Apple iPhone 12 Mini (For all countries)
- Apple iPhone 12 Pro (For all countries)
- Apple iPhone 12 Pro Max (For all countries)

INSTALLATION INSTRUCTIONS



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the mount so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the mount over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw so the mount is firmly in place, but still can be adjusted.
2. To adjust the mount for your device: Place the MagSafe charger on your device. Place the device above the mount and adjust the support. Tighten the screws on the front side of the mount.
3. Carefully press the MagSafe Charger downward and forward so it goes into the mount, tighten the fixing screw. Remove the MagSafe charger from the mount: First loosen the fixing screw then push the MagSafe charger out of the mount.
4. The mount is in place.

The mount to hold an Apple MagSafe Charger is designed for use in ordinary driving conditions. Please be aware that in certain situations, such as driving on bumpy roads or a sudden braking/maneuvering of a vehicle, it is possible that the Apple MagSafe Charger device may be dislodged from the mount holding it. Use of the mount holding an Apple MagSafe Charger is at the user's sole discretion and risk. Brodit AB is not responsible for any damage caused by a device being dislodged from the mount holding a MagSafe Charger.
