

Manual, Assembly instruction: Brodit 712238

With tilt swivel. 3A charging. 12/24V. With Easy-switching system. Charging via pogo pins. Fits device with CipherLab original Rubber Boot PRS3500X01511, with hand strap.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.

2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw so the holder is firmly in place, but still can be adjusted.

3. To place the device in the holder: Place the bottom part of the device into the holder. Press the top of the device forward and in the same time slide the device downward into place in the holder. To remove the device from the holder: Press the upper part of the holder forward. When the device is set free, lift it upward out of the holder.

4. The holder is in place.