

Manual, Assembly instruction: Brodit 213526

Angled mount, High. High strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1: Attaching part (the smallest part) Part 2: Mounting plate

1. Remove the rubber mat in the coin compartment.

2. Place Part 1 in the coin compartment. Press downward on Part 1 so the notches go into the holes at the bottom of the compartment. Pull Part 1 toward you so it hooks into the holes.

3. Place Part 2 in the coin compartment opening so the predrilled holes fit the holes in Part 1. Attach Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.