

Manual, Assembly instruction: Brodit 217081

With MultiMoveClip.

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the product.

1. Place the MultiMoveClip in the desired position and attach it with the enclosed screws.

2. To place the device in the holder: Place the lower part of the device in the lower part of the holder. Press + flip the upper part of the device downward into the holder. To remove the device from the holder: Press the upper part of the holder upward. Pull the upper part of the device away from the holder. Lift the device up out from the holder.

3. To put the holder with the device in it in place: Slide the holder downward onto the MultiMoveClip so it snaps into place. To remove the holder with the device in it: Press forward on the long part of the MultiMoveClip to release the latch, at the same time slide the holder upward away from the MultiMoveClip.

4. The product is in place.