



Product 511615



511615 Passive holder with tilt swivel Adjustable holder. Fits devices without skin. Width: 185-245 mm. Height: 108-173 mm.

With your surfpad in a holder attached in your car you will always have it within easy reach. Safe, neat and convenient! You can connect e.g. a charging cable to the surfpad when it is in the holder. The holder is mounted onto a tilt swivel so you can adjust the angle and switch between portrait and landscape mode.

Features

The adjustable holder fits for devices with the following dimensions: Width: 185-245 mm, Height: 108-173 mm. Measure your device and compare with the holder specifications in order to make sure you have chosen the correct product. Before using the holder you set the size to fit with your device. The holder is designed with the intention to leave as much space open as possible for connection of charging cables and/or headphones.

Important

Tablets should not be installed onto a car's dashboard if they block the view or block key controls. The ProClip is designed for installation of smaller devices (phones), not for large devices (tablets). If you want to place a tablet onto the car's dashboard, each combination of tablet-car must be examined in detail by you in order to determine if such an installation is possible in the specific case. Consideration should be given to the position and how firmly the ProClip is in place, as well as the size of the tablet you wish to use. Brodit will not give any recommendations for such installations.

An installation of a tablet onto a vehicle's dashboard is always done on the customer's own responsibility. Brodit recommends to use tablets on the car's headrest, installed onto a Brodit headrest mount.

EAN: 7320285116153

INSTALLATION INSTRUCTIONS



Please read all of the instructions and look at the pictures before attaching the holder.

1. To adjust the holder for your device: Loosen the locking wheels on the back of the holder, so the sides of the holder can be adjusted. Open up the sides to full size. Place your device in the holder and press the sides together so the device is firmly in place. The resilient right arm should be little stretched. Tighten the locking wheels in order to fixate your setting.

2. To install the holder: Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Tighten the screw until the holder is firmly in place, but still can be adjusted.

3. To place your device in the holder: Insert the top right corner of the device into the holder and press upward/rightward so the resilient arm flexes and you can place the device into the holder. To remove the device: Press the device upward/rightward until it comes loose and can be removed from the holder.

4. The holder is in place.
