

Manual, Assembly instruction: Brodit 806255

Left mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consists of two parts: A mount and a faceplate.

1. Hold the mount over the compartment, as shown in the picture. Press the mount straight downward into the hole.
2. Turn the mount sideways so it hooks under the compartment bottom.
3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. Attach the faceplate to the mount with the included screw.
4. The ProClip mount is firmly in place.