

Manual, Assembly instruction: Brodit 856160

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. This mount consists of two parts: An attaching piece and a faceplate.

1. Place the attaching piece over the accessory mount and slide it downward onto the mount.
2. Press the attaching piece downward so it sits properly in place on the accessory mount.
3. Place the faceplate over the attaching piece so the holes match. Attach the faceplate onto the attaching piece with the included screws.
4. The ProClip mount is in place.