

Manual, Assembly instruction: Brodit 856276

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consists of two parts: a mount and a face plate.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount over the dashboard with the right screw hole in line with the frame of the instrument screen.

2. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap behind the top edge of the dashboard, to widen the gap. Insert the angled edge of the mount into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

3. Align the recessed holes on the face plate with the holes on the mount. If needed, adjust the mount left + right so the front part fits on the instrument screen frame. Attach the face plate to the mount with the included screws.

4. The ProClip mount is in place.