

## Manual, Assembly instruction: Brodit 511625

Adjustable holder. Fits devices with skin. Width: 185-245 mm. Height: 108-173 mm.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the holder.**

**1.** To adjust the holder for your device: Loosen the locking wheels on the back of the holder, so the sides of the holder can be adjusted. Open up the sides to full size. Place your device in the holder and press the sides together so the device is firmly in place. The resilient right arm should be little stretched. Tighten the locking wheels in order to fixate your setting.

**2.** To install the holder: Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Tighten the screw until the holder is firmly in place, but still can be adjusted.

**3.** To place your device in the holder: Insert the top right corner of the device into the holder and press upward/rightward so the resilient arm flexes and you can place the device into the holder. To remove the device: Press the device upward/rightward until it comes loose and can be removed from the holder.

**4.** The holder is in place.