

Manual, Assembly instruction: Brodit 811103

Headrest mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the headrest mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled lower edge of the mount behind the inner headrest panel.
2. Press the lower part of the mount downward and forward. Hook the angled upper edge under the headrest frame.
3. Press forward on the mount so it sits securely in place.
4. The headrest mount is in place.