

Manual, Assembly instruction: Brodit 854557

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Adjust the air vent maximum rightwards. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding panel, to widen the gap.

2. Press the angled edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

3. Adjust the air vent maximum leftwards. Press the gap opener into the gap between the air vent and the surrounding panel. Press the right part of the ProClip leftward so the ProClip flexes slightly. Press the right part of the ProClip forward and release the pressure so the angled right edge is pressed into the gap above the gap opener. Pull out the gap opener. Adjust the air vent into desired direction.

4. The ProClip is in place.